


- D** Montageanleitung
- GB** Assembly instructions
- NL** Handleiding voor de montage
- PL** Instrukcja montażu
- HU** Szerelési útmutató
- RO** Instrucțiunile de montaj
- FR** Notice de montage
- IT** Istruzioni di montaggio
- CZ** Montážní návod
- SK** Návod na montáž
- TR** Montaj talimatı
- RU** Инструкция по монтажу




Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam Имя • Имя • Имя • Имя Деловое • firm • Название	Flint	
Nr. • No. • N° • Номер • C • Sz Typ • Type • Tip • Típus • Tipo	7.7544	

1. ASL 833x330x15mm	1	14. TR 346x278x15mm	2
2. ASR 833x330x15mm	1	15. TRM 346x798x15mm	2
3. BL 1400x330x15mm	1	16. ZB 326x315x15mm	2
4. BO 1400x330x15mm	1	17. EBM 687x315x15mm	2
5. BLE 1399x61x15mm	1	18. EB 326x315x15mm	1
6. MSL 833x315x15mm	1	19. RW 845x339x3mm	2
7. MSR 833x315x15mm	1	20. RWM 845x702x3mm	1
8. SKV 346x157x15mm	2		
9. SKB 295x278x3mm	2		
10. SZL 282x97x12mm	2		
11. SZH 284x97x12mm	2		
12. SZR 282x97x12mm	2		
13. KL 346x318x15mm	1		



A5	0mm	6x	i	Klappenhalter	250	1x
A6	8mm	4x	l			8x
B1		10x	q2			10x
c	6,3x11	4x	q10	M4x9		4x
c1	6,3x19	4x	n	8x30mm		37x
e11	24,3	16x	r			12x
f1		16x	s6	4x27		14x
f8	246	4x	t1	3,5x15		5x
	Auszug					z8



A5	0mm	6x
A6	8mm	4x
B1		10x
c	6,3x11 kurz	4x
c1	6,3x19 lang	4x
e11	24,3	16x
f8	246 Auszug	4x
n	8x30mm	16x
s6	4x27	14x
v		7x
y4	Leim	2x
z8		4x

