





Art. Nr. 24388360; 60253859














LKZ 40947



- | | | | |
|-----------|------------------------------------|-----------|--------------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | IT | Istruzioni di montaggio |
| NL | Handlieding voor de montage | PL | Instrukcja montażu |
| CZ | Montážní návod | SK | Návod na montáž |
| HU | Szerelési útmutató | RO | Instrukțiuni de montaj |
| TR | Montaj talimatı | RU | Инструкция по монтажу |



No	Size/MaB (mm)	Qty	✓	No	Size/MaB (mm)	Qty	✓
1	800x 600x 15	1		4	494x 56x 15	2	
2	758x 558x 15	1		5	405x 50x 50	2	
3	694x 56x 15	2		6	405x 50x 50	2	





3

C 230010
Ø8x32 x2

D 250046
4x50 x8

E 070017
30x30 x4



4

F 070045
Home x1

